

Brinsea Incubation Disinfectant Concentrate

Instructions for Use

Note also the statutory safety warning on the bottle.

Brinsea Incubation Disinfectant concentrate must always be used in solution according to these instructions.

Disinfecting Incubation and Brooding Equipment

ALWAYS ENSURE THAT ELECTRICAL PARTS ARE KEPT DRY.

Remove all debris (eggshell, fluff and debris etc.) from the equipment. Immerse all removable non-electrical parts (egg tray, dividers, covers etc.) in a 100:1 solution of disinfectant for 10 minutes. Discard the solution after each immersion. Use a similar solution, soaked on to a cloth to wipe the cabinet and the covers of any electrical parts. Alternatively the solution can be applied using a spray bottle, *m'()iding eJec'rical p(lr's*. Soak up any puddles of solution and then allow all parts to dry thoroughly before re-assembly. Refer also to manufacturers guidelines for cleaning.

Disinfecting eggs prior to incubation

Remove excess soil from eggs with a knife and dip eggs (individually or in batches) into a solution of 1:100 disinfectant concentrate to water for 1 minute. The solution MUST be about 20°F warmer than the temperature of the egg to prevent the egg contents contracting and drawing solution through shell pores. As the solution cools and becomes contaminated it must be discarded. Gently dry the eggs on paper towel or similar immediately after treatment.

Preventing re-infection

Use a 1:100 solution of disinfectant concentrate in the water reservoir(s) of your incubator or brooder to reduce the possibility of pathogens developing.

Do not allow your clean eggs to be re-infected by later inspection and handling -Brinsea Incubation Disinfectant (in 1:100 solution) is safe to use on your hands before inspecting your eggs or birds. If skin irritation occurs then use rubber gloves.

For further information contact:

Brinsea Products Inc., 704 N Dixie Ave, Titusville, FL 32796-2017 USA.

Toll Free 1-8886677009

Phone 1-321 2677009

Fax 1-321 2676090

Website: www.brinsea.com

e-mail: BrinseaUSA@aol.com